

Roppe BaseMates™ Wall Base

Product Data

Section 9

Resilient Flooring



Maintenance

7.1 DO NOT rub or apply lateral or vertical pressure to the wall base for at least 72 hours after the installation is complete to allow the adhesive to properly cure. Some disinfectants, cleaning agents, floor maintenance products, and pesticides may stain or damage the surface of the wall base. Roppe Pinnacle, BaseMates and Rubber Corner Blocks and factory corners can be routinely cleaned by wiping with a soft cloth slightly dampened with warm water.

CAUTION: Coarse cleaning materials and/or harsh cleaning agents may damage the surface of the base. Do not allow water, solutions or cleaners of any kind to work its way between the wall base joints or top of the wall base, which can have an adverse effect on the adhesive. Always check for compatibility and performance prior to cleaning by utilizing uninstalled material or test in an inconspicuous area before proceeding to determine if the desired results can be achieved without distorting the wall base.

7-09

