

# Roppe Visuellé Wall Base

## Product Data

Section 9

Resilient Flooring



## Maintenance

**7.1 DO NOT** rub or apply lateral or vertical pressure to the wall base for at least 72 hours after the installation is complete to allow the adhesive to properly cure. Some disinfectants, cleaning agents, floor maintenance products, and pesticides may stain or damage the surface of the wall base. Clean the wall base with a soft cloth slightly dampened with a neutral pH (pH 7-8) cleaner such as Spartan Chemical's Damp Mop (800-537-8990) mixed with a warm water solution (1-part Damp Mop mixed with 4-equal parts of warm water). Mix solution thoroughly and clean with a soft cloth sparingly. **DO NOT** allow the solution to dry. Wipe off residue with a smooth clean cloth slightly dampened with cool water, remove the water with a clean soft cloth, and allow the wall base to dry. Do not allow water, solutions or cleaners of any kind to work its way between the wall base joints or top of the wall base, which can have an adverse effect on the adhesive. If a stronger cleaning solution is required, or to remove unwanted floor finish residue, use either Spartan Chemical's Rinse Free Strip (1-part) or Shinline Emulsifier Plus (1-part) diluted with 4-parts water (1-part cleaner mixed with 4- equal parts water) mixed thoroughly to clean the wall base. Always check for compatibility and performance prior to cleaning by utilizing uninstalled material or test in an inconspicuous area before proceeding to determine if the desired results can be achieved without distorting the wall base. Follow the manufacturer's recommendations for dilution and use. **DO NOT** use highly alkaline, highly acidic, or solvent-based cleaners. Apply the diluted cleaning solution to the wall base with a clean soft-cloth. If removing floor finish residue from the wall base, allow the cleaning solution to stand for approximately 10 to 15 minutes; however, **DO NOT** allow the solution to dry. Wipe off residue with a smooth clean cloth slightly dampened with cool water, remove the water with a clean soft cloth, and allow the wall base to dry. Repeat as necessary to remove all unwanted floor finish residue.

### 7.2 Visuellé Optional Painting Instructions:

**7.2.1 Existing Visuellé Painting Instructions:** Even though Visuellé Wall Base will provide years of maintenance free performance, it can be painted if the environments paint theme color has changed, without the added expense of purchasing new wall base. In order to paint Visuellé, first remove any residue by following the procedures noted in 7.1. Once the wall base has been properly cleaned and free of all residues which may interfere with the primer bonding, proceed with priming using a quality primer recommended and compatible with quality acrylic latex paint. Once the primer has properly dried, paint with a quality acrylic latex paint. Follow all primer and paint manufacturer's installation procedures and cautions. Always check for compatibility and performance prior to priming and painting by utilizing uninstalled material or test in an inconspicuous area before proceeding to determine if the desired results can be achieved.

**7.2.2 New Visuellé Installation Painting Instructions:** Visuellé provides the option of painting prior to installation to match paint theme colors. Follow instructions noted in 7.2.1. If Visuellé is to be installed on round or curve surfaces, install wall base first and proceed with priming and painting instructions noted in 7.2.1 to prevent paint from cracking and/or releasing. Make all cuts to wall base prior to priming and painting to prevent paint from cracking and/or releasing.



# Roppe Visuellé Wall Base

## Product Data

Section 9

Resilient Flooring



Always check for compatibility and performance prior to priming and painting by utilizing uninstalled material or test in an inconspicuous area before proceeding to determine if the desired results can be achieved.

4-10

