



ROP360 Acrylic Tile & Stair Tread Adhesive

Description: ROP360 Acrylic Tile and Stair Tread Adhesive is a solvent free, high strength, acrylic adhesive for indoor installations over recommended and properly prepared concrete and wood subfloors only, on grade or above grade. Use of this adhesive is limited to casual foot traffic, in areas where there are no lateral shear stresses or rolling loads, nor in areas that will not be subjected to topical moisture or liquids. ROP360 is specifically designed for the permanent installation of North Coast Collection Tile, SafeTcork Vinyl Tile (excluding ESD Tile), Rubber Tile (excluding 800 Series Rubber Tile, Lug-Back Tile, Recoil, Tuflex & Spike/Skate Resistant Tile), Rubber & Vinyl Stair Treads, (excluding butting stair treads) Stringers and Risers. ROP360 must be used in combination with Roppe ECC Epoxy Caulking Compound (Nose Filler) when installing Rubber & Vinyl Stair Treads.

Sizes: Adhesive is available in 1-gallon and 4-gallon pails. **Color:** Off-White. **Shelf Life:** Limited to one year from date of manufacture stored at 70°F (21°C) in unopened container. **Freeze Thaw Stability:** The adhesive is freeze-thaw stable to 5 cycles at 20°F (6°C); however, it is recommended to protect all adhesive products from freezing. If frozen, DO NOT stir until material has completely thawed. **Clean-Up:** Remove wet adhesive with a soft, clean cloth dampened with warm soapy water. Dried adhesive can be removed using a clean white cloth and denatured alcohol. **Mixing:** No mixing is required.

Installation Temperature Ranges: The installation area, substrate, flooring, associated material and adhesive are to be maintained between 65°F (19°C) and 85°F(30°C) for at least 48 hours before installation, during installation, and thereafter. Room temperature must be maintained between 65°F (19°C) and 85°F (30°C) thereafter to prevent adhesive failure and to prevent distortion or destruction of flooring. In addition, the subfloors temperature range must also be between 65°F (19°C) and 85°F (30°C) prior to installation, during installation and maintained thereafter.

Use: Interior Installation North Coast Collection Tile, SafeTcork Vinyl Tile (excluding ESD Tile), Rubber Tile (excluding 800 Series Rubber Tile, Lug-Back Tile, Recoil, Tuflex & Spike/Skate Resistant Tile), Rubber & Vinyl Stair Treads (excluding butting stair treads) & Rubber & Vinyl Stringers and Risers.

Calculated VOC's: ROP360 Acrylic Tile and Stair Tread Adhesive Calculated VOC's according to California SCAQMD Rule #1168: <13 grams per liter of coating.
SCAQMD Rule 443.1: Grams of VOC per Liter of Material: < 10 gram/liter.

ROP360 Qualifications: Meets CHPS -01350, SCAQMD Rule #1168 & Rule 443.1, CRI Green Label Plus (ID Number 14524) and LEED requirements.

Recommended Substrates: On or above grade and properly prepared concrete and wood subfloors. See Individual Product 10-Part Specification Sheet for complete details, cautions and warnings.

Limitations: For interior installations only. Do not use ROP360 for installations subjected to rolling loads or lateral shear. When installing Rubber & Vinyl Stair Treads, ROP360 must be used in combination with ROPECC (nose filler). Do not apply ROPECC directly over the adhesive/tape being utilized to install the stair treads. Do not use to install rubber & vinyl stair nosings and accessories. Do not use over painted or primed surfaces. Do not use over existing floor-covering. Do not use below grade, over non-porous substrates nor installations subjected to rolling loads and lateral shear stress. Do not use outdoors. There is to be no foot traffic until 48 hours after installation. There is to be no maintenance performed for at least 72 hours after installation.. Do not heat weld until at least 24 hours after installation.

Rubber & Vinyl Stair Tread, Stringer & Riser Preparation: Before applying ROP360 or ROPECC Epoxy Caulking Compound, the stair tread, riser and stringer's entire backing & all material coming in direct contact with either ROP360 or ROPECC must first be thoroughly cleaned with Denatured Alcohol (always follow manufacturer's recommendations, cautions and warnings etc.) and a clean white cloth to remove the factory mold release agent applied during the manufacturing process, along with any other contaminants which could interfere with the bonding process. Once cleaned with Denatured Alcohol, allow backing to dry completely before applying recommended Roppe Adhesive or ROPECC Epoxy Caulking Compound and then test to ensure a successful bond can be achieved.

Cautions: When installing flooring, either use a kneeling board, or for best results, work off the flooring to avoid shifting, adhesive displacement & adhesive telegraphing. Remove wet adhesive immediately. Do not allow adhesive to dry on the flooring, tools or surrounding areas since it may be impossible to remove. Do not allow adhesive to dry or skin-over which will result in either none or inadequate adhesive transfer resulting in an installation failure. All flooring must be properly rolled and re-rolled to ensure proper adhesive transfer.

Subfloor/Substrate Inspection and Preparation: All subfloors/substrates must be inspected prior to installation. All substrates must be clean, smooth, permanently dry, flat, and structurally sound. The substrate must be free of moisture, dust, sealers, primers, paint, oxidation, curing compounds, parting agents, residual adhesives, adhesive removers, hardeners, resinous compounds, solvents, wax, oil, grease, asphalt, gypsum compounds, alkaline salts, excessive carbonation or laitance, mold, mildew, any other extraneous coatings, films, materials and all other foreign matter which might interfere/restrict proper adhesive bonding. DO NOT use sweeping compounds,

solvents, citrus adhesive removers, or acid etching to clean the substrate. DO NOT install flooring over gypsum-based or plaster based leveling or patching compounds. DO NOT install new floor covering over old floor covering, as the old floor covering may not be adequately bonded, hide possible structural defects, or cause plasticizer migration into the new flooring. In renovation or remodel work, remove all existing* adhesive residue so that 100% of the overall area of the original subfloor/substrate is exposed. Follow The Resilient Floor Covering Institute's (RFCI) "Recommended Work Practice for Removal of Existing Floor Covering and Adhesive, and all applicable industry, local, state, and federal standards. Care must be taken to analyze the conditions and correct any problems prior to installation. Follow the manufacturer's recommendations for any patching or underlayment materials, excluding gypsum based or plaster based levelers or patching compounds. *Some previous manufactured asphaltic "cutback" contained asbestos. For removal instructions, refer to the Resilient Floor Covering Institute's publication "Recommended Work Practices for Removal of Resilient Floor Covering".

Concrete Substrates: Concrete substrates on all Grade Levels must be tested in accordance with ASTM F 1869 Standard Test Method for Measuring Moisture Vapor Emission Rate of Concrete Subfloor Using Anhydrous Calcium Chloride or ASTM F 2170 Standard Test Method for Determining Relative Humidity in Concrete Floor Slabs using *in situ* Probes to quantitatively determine the amount of moisture vapor emission at least one week prior to the installation. **Caution:** ASTM F 1869 or ASTM F 2170 tests cannot predict long-term moisture conditions of concrete slabs. Moisture testing only indicates moisture conditions at the time the tests are performed. Before conducting ASTM F 1869 or ASTM F 2170 test, the installation area must be maintained between for 65° F (19°C) and 85° F (30°C) or at least 48 hours prior to testing, during testing and thereafter. In addition, the concrete's temperature range must also be identical to that of the installation area. Conduct three tests for the first 1,000 sq. ft. and one additional test for each 1,000 sq. ft. or fraction thereof per grade level (on, below or above grade). The Vapor Emission Rate shall not exceed 4.0 lbs and Relative Humidity Test shall not exceed 70% when using ROP360. A pH test must be performed to test for excessive alkalinity using a pH pencil or litmus paper and deionized water. A scaly, sandy, or powdery surface is an indication of some form of contaminant, usually excessive alkalis or an alkali-silica residue. A pH reading higher than 8 is an indication of a potential problem and the concrete must be neutralized by rinsing with clear water. Apply clear water with a mop and allow to dry. Re-rinse with clear water, allow to dry and retest to ensure pH level is within acceptable range of 5 to 8 on the pH scale. Continue to neutralize until the pH level is acceptable.

Wood Subfloors: Wood subfloors to be used as subfloors/substrates are to follow the procedures recommended for Subfloor/Substrate Inspection and Preparation (see above). Wood subfloors should be of double layer construction with a minimum thickness of 1". Crawl spaces underneath wood subfloors shall be in compliance with local building code ventilation practices and have clearance of at least 18" of cross-ventilated space between the ground level and joists. Wood joists should be spaced on no more than 16" centers. Place a moisture retarder; having a maximum rating of 1.0 perm, on the top of the ground under the wood subfloor overlapped at least 8". APA, The Engineered Wood Association, Underlayment Grade plywood, minimum 3/8" thick, with a fully sanded face is to be used. Use APA approved exterior grade plywood if finished floors are subjected to moisture. OSB, lauan, maranti, solid-core mahogany, waferboard, particleboard, chipboard, flakeboard, tempered hardboard, glass mesh mortar units or cementitious tile backer boards, sheathing-grade plywood, preservative-treated plywood, or fire-retardant treated plywood are not recommended as some manufacturers may use resins or other adhesives in the manufacturing of the product that may cause discoloration or staining of the flooring. Wood subfloor movement, flexing or instability will cause the flooring installed to release, buckle or become distorted. Do not proceed with the installation until corrective measures have been made. The warranties, performance, installation, and use are the responsibility of the manufacturer and/or contractor. DO NOT use plastic or resin filler to patch cracks. DO NOT use cement or rosin coated nails or staples or solvent-based construction adhesive to adhere the plywood. Installation on a sleeper, a wood subfloor system constructed over the top of concrete, is not recommended. Installation directly over Sturd-I-Floor panels is not recommended. All wood subfloors, single construction plywood floors, single and/or double tongue-and-groove strip floors, and wood plank floors must be prepared to receive resilient flooring in accordance with federal and industry standards. Follow the recommendations of the APA, The Engineered Wood Association, *Design/Construction Guide, Residential and Commercial*, and ASTM F 1482, *Standard Guide to Wood Underlayment Products Available for Use Under Resilient Flooring*, for the installation and proper construction of the panels to receive resilient flooring. It is the contractor's responsibility to determine if the subfloor is acceptable to receive the flooring.

Application: ROP360 Spread coverage using a 1/32" x 1/16" x 1/32" "U" notch trowel is approximately 200-300 square feet per US gallon on a smooth or non-porous substrate. Coverage will vary according to the type of surface, surface texture, spreading angle, and adhesive temperature. Note: Over extremely porous or rough concrete, a 1/16"x 1/16" x 1/16" Square notch trowel may be required (125-184 sq/ft/gal). Over porous substrates, allow adhesive to "flash-off" for 10 minutes before installing. Over smooth or non-porous substrates, allow adhesive to "flash-off" 20 minutes before installing. Approximate Working Time: 20-30 minutes (depending on substrate temperature, humidity & trowel size). At least 90% transfer to the products backing is required.

Rolling: Slowly roll and cross roll with a 100-pound 3-section roller within 15 minutes after each section has been installed. Re-roll & cross roll 30-45 minutes after initial rolling. The rolling time may need to be adjusted to climate conditions. Use a hand roller in areas that cannot be reached with the larger roller.

Warning: Follow all local, state, and federal standards and practices for the proper removal and disposal of flooring, adhesives, or other materials. Follow all local, state, federal, and manufacturer's safety standards for the use of all products and equipment.

* **Notice:** This document is intended as a general guide only. Therefore, refer to Individual Product 10-Part Specification Sheet for complete details, cautions and warnings.

Roppe Corporation
1602 N. Union Street
P.O. Box 1158
Fostoria, Ohio USA 44830-1158
Phone: (419) 435-8546
Toll-Free (800) 537-9527
Fax: (419) 435-1056
Sample Hotline: (877) 726-7534
Email: sales@roppe.com

3/15/09